



Power Source
Engine Control and Engine Immobiliser System
* 1 : Europe 2ZZ-GE
* 2 : Except +1
1
2
3
4
STARTER
ALT
IGNITION SW
ACC RELAY
ECU-IG RELAY
ECU-B RELAY
ST1 RELAY
ST2 RELAY
HEAD LH LWR
HEAD RH LWR
HEAD LH UPR
HEAD RH UPR
TAIL
STOP
ECU-B
ECU-IG
ST1
ST2
ACC
IG2
HEAD LWR
HEAD UPR
TAIL
STOP
50A MAIN
15A IG2
20A(*1) 15A(*2) EFI
10A(*1) 7.5A(*2) IG2 NO. 2
EFI RELAY
7.5A EFI NO. 1
C/OPN RELAY
FUEL PUMP RELAY
FUEL MAIN 1.5m
FUEL SUB 1.5m
BATTERY
AIR PUMP MOTOR
AIR PUMP
I10 IGNITION SW
F17 FUEL PUMP 15A
From ABS ECU <19-3>
From Center Airbag Sensor Assembly<20-2>
To Tachometer [Combi. Meter] <23-3>
To Speedometer [Combi. Meter]
To Cruise Control System
To Stop Lamp Switch
To Daytime Running Light System
Instrument panel brace RH
Engine mount stove RH
Air pump bracket
Front left fender
J18 JUNCTION CONNECTOR
Luggage room left
J11 JUNCTION CONNECTOR
Cowl side panel RH
J13 JUNCTION CONNECTOR
Cowl side panel LH
Front left fender


Engine Control and Engine Immobiliser System
* 1 : Europe 2ZZ-GE
* 3 : 1ZZ-FE
* 4 : 3ZZ-GE
5
6
7
8
ENGINE ECU(MT) OR ENGINE AND ECT ECU(AT)
I9 ISC VALVE
T1 THROTTLE POSITION SENSOR
To Tachometer [Combi. Meter] <23-3>
To Air Conditioning System
To Cruise Control System
To Daytime Running Light System
To Speedometer [Combi. Meter]
Front left fender


Engine Control and Engine Immobiliser System
* 5 : Shielded
* 6 : Except Australia
9
10
11
12
ENGINE ECU(MT) OR ENGINE AND ECT ECU(AT)
T2 TRANSPONDER KEY AMPLIFIER
TRANSPONDER KEY COIL
S5 SECURITY INDICATOR
J10 JUNCTION CONNECTOR
J12 JUNCTION CONNECTOR
J3 JUNCTION CONNECTOR
J11 JUNCTION CONNECTOR
Front left fender
Cylinder head cover LH
Cylinder head cover LH
Cowl side panel LH
Cowl side panel RH