AC2JI–01

# REMOVAL

1. REMOVE COMBINATION METER (See page BE–50)
2. REMOVE ENGINE ECU