BE1EW–01

ADJUSTMENT

HOW TO RESET POWER WINDOW MOTOR

(a) Turn the ignition switch ON.
(b) Fully close the door glass by manual operation.
(c) Using a round bar (2 mm in diameter), keep pressing the reset switch.
(d) With the reset switch pressed, fully open the door glass by manual operation.
(e) Release the round bar from the reset switch and fully close the door glass by manual operation.
(f) Check that the door glass can be fully opened and closed by AUTO operation.

HINT:

- Since jam protection system does not function immediately after resetting, repeat manual open/close operation several times before performing the AUTO operation.
- When performing reverse operation after fully closing the window by AUTO UP, reset the motor again.

(g) Check the power window function.

