BO2T4–01

REMOVAL

1. REMOVE ROOF HEADLINING
(See page BO–89)

2. REMOVE SLIDING ROOF GLASS

(a) Remove the 4 screws.

(b) Pull the glass upward to remove it.

3. REMOVE DRIVE GEAR

NOTICE:

Remove the drive gear with the sliding roof fully closed.

(a) Remove the 2 screws and room light bracket.

(b) Disconnect the connector.

(c) Remove the 2 bolts and drive gear.
Torque: 5.4 N·m (55 kgf·cm, 48 ft·lbf)

4. REMOVE SLIDING ROOF HOUSING

(a) Disconnect the 4 drain hoses from the housing.

(b) Remove the 12 bolts and 6 brackets.
Torque: 5.4 N·m (55 kgf·cm, 48 ft·lbf)

(c) Remove the 4 nuts, then remove the housing.
Torque: 5.4 N·m (55 kgf·cm, 48 ft·lbf)

