BO2T8–01

INSTALLATION

Installation is in the reverse order of removal (See page BO–89).

HINT:

After installing the sliding roof, sliding roof need to be re–initialized.

Refer to BE–100.