BO2TP–01

DISASSEMBLY

1. REMOVE SEATBACK LOCK KNOBS

2. REMOVE SEATBACK LOCK KNOB HOLDERS

3. REMOVE SEATBACK FRAME

(a) Using a clip remover, remove the 5 clips.

(b) Turn over the seatback cover, then remove the hog rings.

(c) Remove the seatback frame from the seatback cover with pad.

(d) Employ the same manner described above to the other side.

4. REMOVE SEATBACK LOCK

(a) Remove the 2 bolts and seatback lock.

(b) Employ the same manner described above to the other side.

5. REMOVE SEATBACK COVER

(a) Remove the hog rings and seatback cover from the seatback pad.

(b) Employ the same manner described above to the other side.

6. REMOVE SEATBACK CUSHION COVER

Remove the hog rings and seat cushion cover from the seat cushion frame with pad.