BR16K–01

INSTALLATION

Installation is in the reverse order of removal (See page BR–58).
AFTER INSTALLATION, CHECK SPEED SENSOR SIGNAL (See page DI–68)