DI6QN–01

DTC	Always ON	ABS ECU Malfunction

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
Always ON	ABS ECU internal malfunction is detected.	• Combination meter • Combination meter circuit • Battery • ABS ECU

INSPECTION PROCEDURE

1	Is DTC output?

Check DTC on page DI–68.

YES → Repair circuit indicated by the code output.

NO

2	Is normal code displayed?

YES → Check and replace ABS ECU.

NO

3	Is ABS warning light go off?

YES → Check and replace ABS ECU.

NO

4	Check battery voltage.

CHECK:

Check the battery voltage.

OK:

10 – 14 V

NG → **Check and repair the charging system.**

OK

5	Check ABS warning light.

PREPARATION:

(a) Disconnect the connector from the ABS ECU.

(b) Connect the terminal WA (A20 – 11) of wire harness and the terminal GND (A20 – 12, 25) of wire harness.

(c) Turn the ignition switch ON.

CHECK:

Check the ABS warning light goes off.

OK → **Check and replace ABS ECU.**

NG

Check for short circuit in harness and connector between ABS warning light, combination meter and ABS ECU (See page IN-30).