MX0A6–01

# INSPECTION

1. INSPECT REVERSE SHIFT WARNING BUZZER SYSTEM (See page BE–52)
2. INSPECT BACK–UP LIGHT SWITCH CONTINUITY (See page BE–33)