






AUTOMATIC TRANSAXLE

PP2DO–02

SST (Special Service Tools)

	09308–00010	Oil Seal Puller	Side gear shaft oil seal
	09223–00010	Cover & Seal Replacer	
	09350–32014	TOYOTA Automatic Transmission Tool Set	
	(09351–32010)	One–way Clutch Test Tool	
	(09351–32020)	Stator Stopper	
	(09351–32150)	Oil Seal Replacer	
	09950–70010	Handle Set	
	(09951–07150)	Handle 150	
	09992–00095	Automatic Transmission Oil Pressure Gauge Set	Line pressure
	(09992–00231)	Adaptor C	Line pressure
	(09992–00271)	Gauge Assy	Line pressure