SA0TJ–02

INSTALLATION

Installation is in the reverse order of removal (See page SA–19).

HINT:

After installation, check the ABS speed sensor signal (See page DI–68) and front wheel alignment (See page SA–4).