SA10P–03

INSTALLATION

Installation is in the reverse order of removal (See page SA–30).

HINT:

After installation, check the front wheel alignment (See page SA–4).