SA1PA–01

# INSTALLATION

**Installation is in the reverse order of removal (See page SA–51).**

HINT:

After installation, check the ABS speed sensor signal (See page DI–68) and rear wheel alignment (See page SA–8).