



AIR REFINER FILTER

AC2JB–01

REPLACEMENT

1. REMOVE AIR REFINER FILTER

(a) Remove the 2 pins in the glove box and open the glove box widely by pulling it down.



(b) Pull out the filter case.

(c) Remove the air refiner filter from the filter case.

2. INSTALL AIR REFINER FILTER

(a) Install the air refiner filter to filter case.

(b) Install the filter case.

(c) Close the glove box and install the 2 pins to it.