
HEADLIGHT AND TAILLIGHT SYSTEM

BE0OR–04

LOCATION



● RHD vehicles for Australia have the light control switch and wiper switch positioned conversely, while those for Europe have them positioned in the same layout with the illustration.

● Center Junction Block shall be installed in the right side for both RHD and LHD.