
BO2SN–01

REMOVAL

1. REMOVE ROOF SIDE RAIL WEATHERSTRIP

(a) Using a clip remover, remove the 4 clips.

(b) Remove the roof side rail weatherstrip.



2. REMOVE ROOF DRIP SIDE MOULDING

Remove the 8 screws and roof drip side moulding.

