

INSTRUMENT PANEL

COMPONENTS














BO2T9–01




Defroster Nozzle
Ⓕor Ⓚ
No. 2 Heater to Register Duct
No. 3 Heater to Register Duct
No. 1 Heater to Register Duct
No. 3 Register
No. 2 Register
RH Lower Pad Insert
No. 1 Register
Ⓕor Ⓖ
No. 1 Pin
Automatic Light Console Sensor
Center Bracket
Hazard Switch
Light Control Rieostat
Security Indicator
Window Lock Switch
Instrument Panel Wire
P
H12630

HINT:
Screw shapes and sizes are indicated in the table below. The codes (”A” – ”N”) correspond to those indicated on the previous page.

mm (in.)

	Shape	Size		Shape	Size		Shape	Size
Ⓐ		ø = 8 (0.32) L = 16 (0.63)	Ⓑ		ø = 8 (0.32) L = 15 (0.59)	Ⓒ		ø = 6 (0.24) L = 22 (0.87)
Ⓓ		ø = 6 (0.24) L = 16 (0.63)	Ⓔ		ø = 6 (0.24) L = 18 (0.71)	Ⓕ		ø = 5.22 (0.2055) L = 16 (0.63)
Ⓖ		ø =5.22 (0.2055) L = 16 (0.63)	Ⓗ		ø = 5 (0.20) L = 18 (0.71)	Ⓘ		ø = 5 (0.20) L = 16 (0.63)
Ⓙ		ø = 5 (0.20) L = 16 (0.63)	Ⓚ		ø = 5 (0.20) L = 14 (0.55)	Ⓛ		ø = 4 (0.16) L = 16 (0.63)
Ⓜ		ø = 8 (0.32)	Ⓝ		ø = 6 (0.24)			

P

H12659