BO2TM–01

# INSTALLATION

## INSTALL FRONT SEAT

(a) Mount the front seat to the vehicle.

**NOTICE:**

**Be careful not to damage the body.**

(b) Connect the connectors.

(c) Slide the front seat to the most front position.

(d) Tighten the bolts on the rear side temporarily, starting from the bolt on the inner side tighten them completely.

**Torque: 37 N·m (375 kgf·cm, 27 ft·lbf)**

(e) Slide the seat to the most rear position to install the bolts on the front side.

**Torque: 37 N·m (375 kgf·cm, 27 ft·lbf)**

(f) Install the seat track covers.