





BO2U0–01

INSPECTION

INSPECT FUEL TANK AND LINE

(a) Check the fuel lines for cracks or leakage, and all connections for deformation.

(b) Check the fuel tank for deformation, cracks fuel leakage or tank band looseness.

(c) Check the filter neck for damage or fuel leakage.

(d) Hose and tube connections are as shown in the illustration.

If a problem is found, repair or replace the part as necessary.