BR15K–01

INSTALLATION

Installation is in the reverse order of removal (See page BR–11).

HINT:

- Before installation, adjust length of brake booster push rod (See page BR–17 or BR–22).
- After installation, fill the brake reservoir with brake fluid, bleed the brake system (See page BR–4), and check for leaks.
- Check and adjust brake pedal (See page BR–6).