BR167–01

REASSEMBLY

Reassembly is in the reverse order of disassembly (See page BR–40).

NOTICE:

Apply lithium soap base glycol grease to the parts indicated by the arrows (See page BR–38).