BR168–01

INSTALLATION

Installation is in the reverse order of removal (See page BR–39).

HINT:

- After installation, fill the brake reservoir with brake fluid and bleed the brake system (See page BR–4).
- Check for leaks.