BR16H–01

INSTALLATION

Installation is in the reverse order of removal (See page BR–55).

HINT:

- After installation, fill the brake reservoir with brake fluid and bleed brake system (See page BR–4).
- Check for leaks.