
CRUISE CONTROL SYSTEM

HOW TO PROCEED WITH TROUBLESHOOTING

DI08F–1

Troubleshoot in accordance with the procedure on the following page.



Items inside ▱ are titles of pages in this manual with the page number indicated in the bottom portion. See the indicated pages for detailed explanations.

Step 2, 5: Diagnostic steps permitting the use of the hand–held tester or break–out–box.