DI08Q–16

DTC	23	Vehicle Speed Signal Abnormal

CIRCUIT DESCRIPTION

See page DI–296.

DTC No.	Detection Item	Trouble Area
23	Vehicle speed sensor pulse is abnormal.	• Vehicle speed sensor • Cruise control ECU

WIRING DIAGRAM

See page DI–296.

INSPECTION PROCEDURE

1	Check vehicle speed sensor (See page BE–52).

NG → Replace vehicle speed sensor.

OK →

Check and replace cruise control ECU (See page IN–30).