
ENGINE IMMOBILISER SYSTEM

DI1AJ–19

HOW TO PROCEED WITH TROUBLESHOOTING

Troubleshoot in accordance with the procedure on the following pages.



Items inside ▱ are titles of pages in this manual, with the page number in the bottom portion. See the pages for detailed explanations.

Step 2, 5 : Diagnostic steps permitting the use of the hand–held tester or break–out–box.