MX01E–03

INSTALLATION

Installation is in the reverse order of removal (See page MX–4).

HINT:

After installation, check and inspect items as follows.

- Bleed power steering system (See page SR–4).
- Front wheel alignment (See page SA–4).
- Do the road test.