





























SUSPENSION AND AXLE

PP2ET–01

SST (Special Service Tools)

	09214–76011	Crankshaft Pulley Replacer	Rear axle
	09240–00020	Wire Gauge Set	Front drive shaft
	09506–35010	Differential Drive Pinion Rear Bearing Replacer	Front drive shaft
	09520–00031	Rear Axle Shaft Puller	
	(09520–00040)	Shocker	Front axle Rear axle
	(09521–00010)	Attachment	Front axle
	(09521–00020)	Rod with Grip	Front axle Rear axle
	09520–01010	Drive Shaft Remover Attachment	Front drive shaft
	09520–24010	Differential Side Gear Shaft Puller	Front drive shaft
	(09520–32040)	Shocker Set	
	09521–24010	Drive Shaft Boot Clamping Tool	Front drive shaft
	09527–17011	Rear Axle Shaft Bearing Remover	Front axle

	09555–55010	Differential Drive Pinion Bearing Replacer	Front axle
	09608–16042	Front Hub Bearing Adjusting Tool	Front drive shaft
	(09608–02021)	Bolt & Nut	
	(09608–02041)	Retainer	
	09608–32010	Steering Knuckle Oil Seal Replacer	Front axle
	09610–20012	Pitman Arm Puller	Front axle Front drive shaft Front suspension
	09628–10011	Ball Joint Puller	Front axle Rear axle
	09628–62011	Ball Joint Puller	Front axle Front suspension
	09710–30021	Suspension Bushing Tool Set	Front drive shaft
	(09710–03141)	Bushing Remover Base	
	09727–30021	Coil Spring Compressor	Front suspension Rear suspension
	(09727–00010)	Bolt Set	
	(09727–00021)	Arm Set	

	(09727–00031)	Compressor	
	09729–22031	Front Spring Upper Seat Holder	Front suspension
	09930–00010	Drive Shaft Nut Chisel	Front axle Front drive shaft
	09950–00020	Bearing Remover	Front drive shaft Rear axle
	09950–60010	Replacer Set	
	(09951–00380)	Replacer 38	Front axle
	(09951–00550)	Replacer 55	Front axle
	(09951–00650)	Replacer 65	Front axle Front drive shaft
	09950–60020	Replacer Set No.2	Front axle
	(09951–00730)	Replacer 73	
	09950–70010	Handle Set	Front axle Front drive shaft
	(09951–07150)	Handle 150	