RS0JV–01

INSTALLATION

HINT:

For step 1 to 4, refer to page SR–20.

1. **INSTALL SPIRAL CABLE**
2. **INSTALL UPPER AND LOWER COLUMN COVERS**
3. **INSTALL STEERING WHEEL**
4. **INSTALL STEERING WHEEL PAD**