SA1OT–01

# INSTALLATION

**Installation is in the reverse order of removal (See page SA–38).**

HINT:

After installation, check the front wheel alignment (See page SA–4).