SA1OY–01

INSTALLATION

Installation is in the reverse order of removal (See page SA–58).

HINT:

After installation, check the rear wheel alignment (See page SA–8).